



# CRESCCENT ARCH

## Louvered Arch with Movable Slats

### INSTALLATION INSTRUCTIONS

Contents:    1 Louvered Arch  
                     3 Mounting Screws

#### To Mount Arch:

---

Step 1. Center the arch in the window opening to assure that it will fit properly.

Step 2. Locate the three holes in the frame of the arch for attaching the arch to the window opening. (Fig 1)

Step 3. With a pencil, mark the hole positions on the window frame.

NOTE: Make sure the Arch will be LEVEL in the window opening.

Step 4. Drill pilot holes for the screws into the window frame.

Step 5. Fasten the arch to the window opening using the three supplied wood screws.

Step 6. Center the arch in the window opening by adjusting the tightness of the three mounting screws. (Fig 2)

Step 7. Open and close the louvers by rotating manually to check that the arch is operating properly.

#### Care & Cleaning:

---

- Occasional light dusting with a feather duster or gentle vacuuming with a brush attachment is all that is required to maintain like-new appearance.
- Spot clean with a soft cloth or moistened sponge if arch becomes soiled.

