



HOW TO MEASURE: WOOD & FAUX WOOD BLINDS

Please use a steel tape measure to ensure the proper measurements.
 Measure to the nearest eighth of an inch (1/8").
 Measure each window individually even if they look the same.
 Always measure and record the width first, then height.
 Reversing the width measurement for the height measurement is the most common ordering mistake.



Inside Mount



Step 1. Measure the width of the opening at the top, middle, and bottom of window. Record the narrowest of the 3 measurements. This is your ordering width. The factory will make the necessary deductions to ensure a proper fit. **DO NOT TAKE A DEDUCTION.**

Step 2. Measure the height of the opening on the left, center, and right. Record the longest of the 3 measurements. This is your ordering height.

Please note: Inside mount measurements represent the exact window opening, do not add to or subtract from your measurements. Factory deductions: 1/2" from blind width only.

Minimum Depth

You'll need this much unobstructed depth, including cranks, handles, locks, etc., to inside mount this treatment.


Flush Mount

For the face of your treatment to be flush with the wall or window frame, your frame depth must be the same or greater than the Flush Mount depth required.



	Minimum Depth Required	Flush Mount Beaded Valance	Flush Mount Crown Valance
1" Wood Blinds	1"	3"	
2" Wood Blinds	1"	2 1/4"	3 1/4"
2" Faux Wood Blinds	1"	3"	3 1/2"
2 1/2" Wood Blinds	1 1/4"	3 1/4"	3 3/4"
2 1/2" Faux Wood Blinds	1 1/4"	3 1/4"	3 3/4"

Outside Mount



Step 1. Measure the width of the area you wish to cover. We recommend adding overlap to reduce light leakage around the blind. See *Recommended Overlap*. This is your ordering width.

Step 2. Decide if the headrail will be installed on or above the window molding. You will need a flat surface area. Measure the height of the area you wish to cover. This is your ordering height.


Please note: Outside mount measurements represent the exact blind size. No deductions will be made by the factory. **PROVIDE EXACT DIMENSIONS.**

	OB Mounting Surface Required	Recommended Overlap - Width	Recommended Overlap - Height
1" Wood Blinds	1 1/4"	1 1/2" each side	2" above
2" Wood Blinds	1 3/4"	1 1/2" each side	2" above
2" Faux Wood Blinds	1 3/4"	1 1/2" each side	2" above
2 1/2" Wood Blinds	1 3/4"	1 1/2" each side	2" above
2 1/2" Faux Wood Blinds	1 3/4"	1 1/2" each side	2" above

Please see Product Stacking Considerations on the next page.

Product Stacking Considerations

The chart shows approximately how much of your window area will be covered when your window treatment is fully drawn open. If you feel too much of the window will be covered, consider Outside Mount. If space allows, mounting brackets can be raised higher above the window frame to reduce the amount of window covered by the treatment.



Stacking Chart

Blind Height	1" Woods	2" Woods	2 1/2" Woods	2" Faux	2 1/2" Faux	Tightclose
30	6"	5 1/2"	5 1/4"	5 1/4"	5 1/4"	5 3/4"
36	7"	6"	5 5/8"	5 3/4"	5 5/8"	6 3/8"
42	7 3/4"	6 1/2"	6"	6 1/4"	6"	6 3/4"
48	8 3/4"	7"	6 1/2"	6 3/4"	6 1/2"	7 1/2"
54	9 1/2"	7 1/2"	6 3/4"	7 1/4"	6 3/4"	8"
60	10 1/2"	8"	7 1/8"	7 3/4"	7 1/8"	8 1/2"
66	11 1/2"	8 1/2"	7 1/2"	8 1/4"	7 1/2"	9"
72	12"	9"	8"	8 3/4"	8"	9 1/2"
78	13 1/8"	9 1/2"	8 3/8"	9 1/4"	8 3/8"	10"
84	14"	10"	8 3/4"	9 3/4"	8 3/4"	10 1/2"
90	14 7/8"	10 1/4"	9 1/8"	10"	9 1/8"	10 3/4"
96	15 3/4"	10 3/4"	9 1/2"	10 1/2"	9 1/2"	11 1/4"